

INSTALLATION INSTRUCTION

تعليمات التركيب

LED MODULE MR11 & MR16

وحدة إضاءة موديول إم أر ١١ أو إم أر ١٦

Attentions:

- This Series Module light source comes with external power supply.
- Please keep 75mm air vent around the lamp.
- The light fixture cannot be covered by an insulating liner or similar material.
- Do not install lamps over hot objects or damp places.
- Be sure to cut off the power supply before maintaining, installing or replacing the lamp.
- When inspecting and repairing lamps and lanterns, please entrust professional operators.

تنبيهات:

- يأتي مصدر ضوء وحدة الإضاءة مزودًا بمصدر طاقة خارجي.
- يرجى الاحتفاظ بفتحة تهوية ٧٥ ملمتر حول المصباح.
- لا يمكن تغطية وحدة الإضاءة لعزل أي مواد مماثلة.
- لا تقم بتركيب المصابيح فوق الأجسام الساخنة أو الأماكن الرطبة.
- تأكد من فصل التيار الكهربائي قبل صيانة أو تركيب أو تثبيت المصباح.
- يتم فحص وتركيب المصابيح من قبل فني مؤهل.

