



- 1: Insert the gripper through ceiling bracket, then screw the nut.
- 2: Drill 2 holes on the ceiling, pay attention to the hole pitch and hole diameter, then put plastic parts into the ceiling holes and tighten the screw to install bracket bar on the ceiling.
- 3: Use canopy to cover bracket bar with its edge close to the ceiling, then secure screw.
- 4: Install the ceiling bracket to upper groove of track to the right place, then secure screw.

- ١: أدخل القابض من خلال قاعدة التركيب، ثم قم بلف وتركيب الصمامولة للتركيب.
- ٢: احفر فتحتين في السقف، والانتبه إلى حفرة قطر مناسب، ثم ضع الأجزاء البلاستيكية في فتحات السقف وشد البرغي لثبيت شريط التركيب على السقف.
- ٣: استخدم الغطاء لتغطية الحامل بحافته لتكون قريبة من السقف، ثم قم بثبيت البرغي.
- ٤: قم بثبيت شريط التركيب في الأخدود العلوي للمسار في المكان الصحيح، ثم قم بثبيت البراغي.