

illus

illumination

USER MANUAL دليل المستخدم



تعليمات تغيير المصباح

- 1 - عند تغيير المصباح قم بفصل التيار الكهربى اولا .
- 2 - قم بفتح الغطاء المودى الى المصباح اذا كان موجود .
- 3 - قم بتحريك المصباح دائريا يرفق حتى يخرج من الكبس .
- 4 - قبل ان تقوم بتشغيل التيار الكهربى تأكد اولا بتركيب المصباح جيدا .
- 5 - اذا كان الكشاف يحتوى على غطاء اعد الغطاء باحكام ثم قم بتشغيل تيار الكهرباه
- 6 - لا تلمس المصباح بيدين عاريتين.

تعليمات الامان

- 1 - قبل الشروع فى التركيب قم بفصل تيار الكهرباه اولا
- 2 - بعد تشغيل الكشاف تبدأ درجه حرارة المصباح فى ارتفاع لذا يرجى عدم لمس المصباح باليد.
- 3 - اذا تريد تغيير المصباح او زجاج المصباح ان وجد افضل التيار الكهربى وانتظر حتى يبرد .
- 4 - يجب ان لا تتجاوز قوة الكهرباه (الوات) عن القيمه المحدده والملصوقه على الكشاف .
- 5 - يجب عدم النظر الى المصباح بالعين المباشرة حتى تؤثر على عينك
- 6 - عند تحطم الزجاج الواقى يجب على الفور تغييره وعدم استخدام المصباح بدون زجاج واقى
- 7 - يرجى التأكد من توصيل السلك الأرضى .
- 8 - هذا النوع من الكشاف يستخدم فى داخل البيوت
- 9 - تحذير هام : فى حالة تلف السلك او الكبس او حدوث خلل بالتوصيلات الكهربائيه يجب فصل التيار فورا عن المنتج وعدم استخدامه والرجوع الى البائع
- 10 - اذا فيه اى استفسار عن المنتج يرجى مراجعه البائع
- 11 - هذا المنتج من الحديد والالومنيوم
- 12 - صنع فى الصين

Direction of chang Bulb

- 1 pls turn off the power frist before you do any thing
- 2- open Down light access cover if have
- 3 twist out the bulb A lightly
- 4- Do not Touch the Bulb with bare hand.
- 5 When installing Bulb , please twist the Bulb in the socket carefully .
- 6 Before turning on power , replace lamp Access.

Safety Directions.

- 1 Before starting the installation, please ensure the power is off
- 2 After turning off the power, temperature of bulb will be very Hot, pls don't touch the bulb with your hand
- 3 If should change the bulb,pls cut off power frist,and wait till the bulb became cooled enough the start to change
- 4 The bulb must not exceed th specified wattage on sticker mansion .
- 5 Be sure to connect the ground lead .
- 6 When protective glasses damaged, must change new one. And don't use without protective glasses
- 7 Please do not look at the light bulb directly.
- 8 this kind of light use for indoor only
- 9 If you need any more information pls contact the seller.
- 10 in case wire damage or holder or any other problem please contact the seller
- 11 This prodcut is make of Iron and Aluminum
- 12 this prodcut is Made in china

تحذير هام : فى حالة تلف السلك او الكبس او حدوث خلل بالتوصيلات الكهربائيه يجب فصل التيار فورا عن المنتج وعدم استخدامه والرجوع الى البائع

Warning: in case if the main Wire or Holder or any Spare Part of this products is required, please contact with the seller

illus

illumination

- (1): This product for indoor use only.
- (2): The related ambient temperature is 45°C.
- (3): This product must be installed by an eligible electrician.
- (4): Be sure to fit the lamp with the ceiling strong enough.
- (5): Turn off electrical power before starting installation.
- (6): While the lamp is on work, don't touch lamp-shade by hand.
- (7): Do not touch luminaire with wet hand or cloth, also do not touch the top of the shade.
- (8): The luminaire is class II appliance.
- (9): For models with input power cord, if the supply cord is damaged, it must be replaced by a special cord or assembly available from the manufacturer or its service agent.
- (10): The light source contained in this luminaire shall only be replaced by the manufacturer or his service agent or a similar qualified person.
- (11): Luminaire not suitable for covering with thermally insulating material.

- (١): هذا المنتج للاستخدام الداخلي فقط.
- (٢): درجة الحرارة المحيطة ذات الصلة هي ٤٥ درجة مئوية.
- (٣): يجب تثبيت هذا المنتج بواسطة فني متخصص.
- (٤): تأكد من ملاءمة المصباح مع السقف عند التثبيت بدرجة كافية.
- (٥): قم بإيقاف تشغيل الطاقة الكهربائية قبل بدء التثبيت.
- (٦): أثناء تشغيل المصباح، لا تلمس غطاء المصباح يدوياً.
- (٧): لا تلمس الإنارة باليد أو قطعة فماش مبللة، ولا تلمس أيضاً الجزء العلوي من الغطاء.

- (٨): المصباح من التصنيف رقم II للتطبيق.
- (٩): بالنسبة للطرازات المزودة بسلك طاقة الإدخال، في حالة تلف سلك الطاقة، يجب استبداله بسلك خاص أو مجموعة متوفرة من الشركة المصنعة أو وكيل خدماتها.
- (١٠): يجب استبدال مصدر الضوء الموجود في وحدة الإنارة فقط من قبل الشركة المصنعة أو وكيل خدماته أو شخص مؤهل مماثل.
- (١١): وحدة الإضاءة غير مناسبة للتغطية بمواد عازلة للحرارة.

illus

illumination

1 OFF غلق

2 اضغط هنا Press here

3 خطوات التركيب Install

4 تشغيل تشغيل

5 اكتمل التركيب The installation is complete

تركيب افقي Horizontal installation

تركيب عمودي Vertical installation

15 mins

يرجى عدم ملامسة الضوء أو المسار أثناء التشغيل
Please do not use your bare hands to adjust the core when the light is on

اغلق الضوء وانتظر ١٥ دقيقة لتعديل مكان الضوء
Turn off the power and wait for 15mins before adjust the core with bare hand



*The product is imported and distributed by Lighting Stores Est. For Trading.
*For any further information or notes, please send your inquiry to Email: illus@lightingstores.com.sa