

### Surface Mounted Luminaire (Wall) وحدة إضاءة سطحية (جدارية)

#### Attentions:


- Luminaire should be installed by professional electrician.
- Check the power switch has been turned off.
- Please read this user guide carefully before installation and keep for future reference.
- If the cable or flexible external wire of this lamp is damaged, it must be replaced exclusively by the manufacturer, its service agent or a qualified technician to avoid a hazard.

#### تنبيهات:

- يجب أن يتم تثبيت وحدة الإضاءة بواسطة كهربائي محترف.
- تحقق من إغلاق مفتاح التشغيل.
- يرجى قراءة دليل المستخدم بعناية قبل التثبيت، والاحتفاظ به للرجوع إليه في المستقبل.
- في حالة تلف الكابل أو السلك الخارجي المرن لهذا المصباح، يجب استبداله حصريًا من قبل الشركة المصنعة أو وكيل الخدمة الخاص به أو فني مؤهل لتجنب حدوث خطر.

|                           |                    |                                      |                         |
|---------------------------|--------------------|--------------------------------------|-------------------------|
| Model                     | ILSSMOWF22         | ILSSMOWF22                           | الموديل                 |
| Power                     | Max.18W            | أقصى قدرة ١٨ واط                     | القدرة                  |
| Input Voltage & Frequency | AC220-240V,50/60Hz | تيار متردد ٢٢٠-٢٤٠ فولت، ٦٠/٥٠ هيرتز | الجهد الكهربائي والتردد |
| IP                        | 54                 | 04                                   | درجة الحماية            |
| TA                        | 45°C               | ٤٥ درجة                              | درجة الحرارة            |

### COMPONENTS AND TOOLS المكونات والأدوات



### INSTALLATION STEPS خطوات التثبيت

