

Spike Projector Luminaires
وحدة إضاءة غرس


Attentions:

- Luminaire should be installed by professional electrician.
- Check the power switch has been turned off.
- Please read this user guide carefully before installation and keep for future reference.
- If the cable or flexible external wire of this lamp is damaged, it must be replaced exclusively by the manufacturer, its service agent or a qualified technician to avoid a hazard.
- Terminal block not included, Installation must be carried out by a qualified technician.

تنبيهات:

- يجب أن يتم تثبيت وحدة الإضاءة بواسطة كهربائي محترف.
- تحقق من إغلاق مفتاح التشغيل.
- يرجى قراءة دليل المستخدم بعناية قبل التثبيت، والاحتفاظ به للرجوع إليه في المستقبل.
- في حالة تلف الكبل أو السلك الخارجي المرن لهذا المصباح، يجب استبداله حصرياً من قبل الشركة المصنعة أو وكيل الخدمة الخاص به أو فني مؤهل لتجنب حدوث خطر.
- المنتج لا يتضمن صندوق التوصيل، يجب أن يتم التثبيت من قبل فني مؤهل.

Model	ILSSPMOPJF05	ILSSPMOPJF05	الموديل
Power	Max.9W	أقصى قدرة 9 واط	القدرة
Input Voltage & Frequency	AC220-240V,50/60Hz	تيار متردد ٢٢٠-٢٤٠ فولت، ٦٠/٥٠ هيرتز	الجهد الكهربائي والتردد
IP	65	٦٥	درجة الحماية
TA	45°C	٤٥ درجة	درجة الحرارة

COMPONENTS AND TOOLS
المكونات والأدواتINSTALLATION STEPS
خطوات التثبيت