

## LED IN-GROUND LUMINAIRE

## وحدة إضاءة أرضية ليد

## Attentions:

- Luminaire should be installed by professional electrician.
- Check the power switch has been turned off.
- Please read this user guide carefully before installation and keep for future reference.
- If the cable or flexible external wire of this lamp is damaged, it must be replaced exclusively by the manufacturer, its service agent or a qualified technician to avoid a hazard.
- The light source in this lighting unit should only be replaced by the manufacturer, his service agent or a qualified technician.
- Terminal block not included. Installation must be carried out by a qualified technician.


## تنبيهات:

- يجب أن يتم تثبيت وحدة الإضاءة بواسطة كهربائي محترف.
- تحقق من إيقاف تشغيل مفتاح الطاقة.
- يرجى قراءة دليل المستخدم بعناية قبل التثبيت، والاحتفاظ به للرجوع إليه في المستقبل.
- في حالة تلف الكبل أو السلك الخارجي المرين لهذا المصباح، يجب استبداله حصريا من قبل الشركة المصنعة أو وكيل الخدمة الخاص به أو فني مؤهل لتجنب حدوث خطر.
- يجب استبدال مصدر الضوء الموجود في وحدة الإضاءة هذه فقط من قبل الشركة المصنعة أو وكيل الخدمة الخاص به أو فني مؤهل.
- المنتج لا يتضمن صندوق التوصيل. يجب أن يتم التثبيت من قبل فني مؤهل.

Model	ILS17RMOIGL01	ILS17RMOIGL01	الموديل
Power	17W	١٧ واط	القدرة
Input Voltage & Frequency	AC220-240V,50/60Hz	تيار متردد ٢٢٠-٢٤٠ فولت، ٥٠/٦٠ هيرتز	الجهود الكهربائي والتردد
IP	67	٦٧	درجة الحماية
TA	45°C	٤٥ درجة	درجة الحرارة

## COMPONENTS AND TOOLS

## المكونات والأدوات



## INSTALLATION STEPS

## خطوات التثبيت

