

TECHNICAL DATA

Aluminum profile to help resist slipping

Reference number : Am702

Size: 12x20x2500 mm

Thickness: ± 1 mm

(There may be slight size differences)

CH01370023	Am702-1M Aluminum Silver Matt 20 X 2500 Mm	Silver Matt
CH01370024	Am702-2S Aluminum Silver Bright 20 X 2500 Mm	Silver Bright

Description	Standard
Length	2500 mm
Width	20 mm
Thickness	± 1 mm
Material	Aluminum
Fire resistance	UNE 23-727-90
Appearance and color	EN 12373-1
Lightfastness	Excellent

Installation :

It's widely applied for fixing shower glass of tile, or stone, wooden laminated, boards and decorative material.

1. Cut profile to the desired length and apply the adhesive on the support where the profile will be laid.
2. Remove carefully any remains of oil, fat and dirt from the surface where the profile will be laid.
3. Apply the adhesive to the surface of the substrate.
4. Insert the glass into the profile that is between the tile or (wood board or stone, etc.).
5. Apply adhesive to the back of the tiles, then place the tiles on the door and wall, aligning them with the profile, leaving 2mm between spacers.
6. Fill the joints between the surface and the tiles with grouting material. Then remove all residue from the surface immediately

Cleaning and maintenance :

The product must be cleaned periodically with a soft mop. If you use a neutral liquid cleaner, you must rinse the profile with cold water and dry it to remove the humidity excess. The persistent dirtiness can be removed by using cleaning approved agents lightly abrasive or a grid covered with polished powder neutral. Steel wool, abrasive cleaners, souring products as well as strong acids (hydrochloric and perchloric), strong bases (caustic soda or ammonia) or carbonated solutions are not recommended. Citric acid is neither recommended because it dissolves the protective layer of the surface of aluminium. Waxes, petrolatum, lanolin or similar substances are not appropriate. Solvents containing haloalkanes (hydrofluoroether and chlorinated solvents) and curing accelerators containing chlorides should not be used (use special accelerators free of chlorides)

Checked By QUALITY DEPARTMENT

occupational health and safety
GB/T45001-2020/ISO 45001:2018



Quality Management System ISO 9001

